

713=Q05-21203-01110
 713=Q05-21103-01084
 713=W64-01211-03174
 713=W64-16212-00005
 713=Q05-21403-01057
 713=R95-01340-03300
 713=W52-90500-23914
 713=W52-90500-28075
 713=W52-00200-08623
 713=W52-10509-30924
 713=W52-70500-01655
 713=G52-10500-24614
 713=Y62-00100-27042
 713=W52-90500-27042
 713=T97-13241-06121
 713=NUT-1/4"JACK
 713=Q05-26500-05736
 713=Q05-06001-00928
 713=Q05-25204-00674
 713=Q05-26102-02417
 713=Q05-19702-02416
 713=Q05-61100-03693
 713=Y03-82041-00969
 713=Y03-37345-13868
 713=803-31645-02934
 713=803-32245-02914
 713=Y03-33241-02883
 713=W81-10792-22512
 713=W81-19132-22554
 713=W81-19952-22553
 713=W81-79142-25888
 713=W81-09122-24493
 713=W81-29092-53545
 713=W81-11222-22550
 713=Q00-97102-00000
 713=Q04-00000-08216
 713=Q65-00100-07274
 713=A62-00300-06870
 713=Q65-22000-22174
 713=Q65-00200-07269
 713=Q65-00100-07273
 713=Q65-22000-22171
 713=G58-00100-09790
 713=X77-61000-02056
 713=Y86-00023-17512
 713=W54-13700-23341
 713=Y77-03422-02778
 713=Y77-03442-02780
 713=Z71-13194-33503
 713=Z71-15520-03503
 713=X71-60250-00046
 713=X75-60290-08531
 713=X71-60340-01854
 713=X71-60250-48914
 713=X71-60440-52166
 713=WASHER-1/4"JACK
 713=X77-61800-52072

JACK,1/4" INPUT W/PCB GMX210
 JACK,1/4" INPUT W/PCB GMX212
 JACK,INPUT B212A/GMX112/GX212
 JACK,INPUT W/O PCB BX4500/4210
 JACK,INPUT W/PCB GX110/GMX112
 JACK,XLR INPUT ACX450/UB1202
 KNOB,BLACK VAMP
 KNOB,EFFECTS/REVERB LX112/210
 KNOB,EQ FADER K1800FX/PMH880S
 KNOB,FADER BLACK/WHITE XENYX
 KNOB,FADER DJX700
 KNOB,FADER ULTRAGRAPH/GEQ3102
 KNOB,MID FREQUENCY AC112
 KNOB,PARAMETER AC112/ACX1000
 LAMP,BAYONET TYPE UTRA Q T1951
 NUT,1/4" INPUT JACK GMX AMPS
 PCB LPA1180 PMP518M
 PCB,MAIN (AMP ASSY) BX300/B300
 PCB,MAIN W/O PWR AMP ICS B2031
 PCB,POWER AMP B212A
 PCB,POWER AMP B215A
 PCB,POWER AMP PMH2000
 POT GAIN PMH3000
 POT,GAIN ULTRACOUSTIC 1000
 POT,MONO CHANNEL MX802A
 POT,STEREO CHANNEL MX802A
 POT,VOLUME EP2500
 POWER SUPPLY DSP110 SHARK
 POWER SUPPLY MX1604A/MX802A
 POWER SUPPLY MXUL1 MX1804/2004
 POWER SUPPLY MXUL3 MX/UB/XENYX
 POWER SUPPLY MXUL5 UB1002/1202
 POWER SUPPLY MXUL6 UB1202FX
 POWER SUPPLY UBB1002/UB1002
 POWER SUPPLY,RACKMOUNT MX3282A
 POWER SUPPLY,INT UB1832/2442FXPO
 RACK EAR (EACH) MX2442
 RACK EAR (EACH) PMP518M
 RACK EAR (EACH) UB2222/XENYX1832
 RACK EAR (EACH) XENYX1204FX
 RACK EAR (EACH) XENYX1832/2222
 RACK EAR (EACH) XENYX2442FX
 ROD HOLDER,KEY COVER EG2080-RW
 SPEAKER 10" BA410/BX4210A
 SWITCH,SLIDE GMX212
 SWITCH,BUMP LC1224
 SWITCH,MAIN/AUX1 EQ SL3242FXPR
 SWITCH,MUTE STEREO CH MX2642A
 TRANSISTOR 2SA1943 EP1500
 TRANSISTOR 2SC5200 EP1500
 TWEETER ASSY B2031/2031A/2031P
 TWEETER ASSY BB410/BB115
 TWEETER B212A/B215A
 TWEETER K300FX
 TWEETER,HORN F1220/B1520&PRO
 WASHER,1/4" INPUT JACK GMX AMP
 WOOFER 18" BXL1800A/B1800X/PRO

BEYERDYNAMIC [VIEW ONLINE](#)

014=126.748
 014=126.756
 014=156.337
 014=317.314
 014=941.430
 014=505.250
 014=WK250.30/07
 014=205.443
 014=445.304
 014=922.899
 014=925.626
 014=107.948
 014=108.448
 014=108.421
 014=108.596
 014=108.464
 014=442.704
 014=942.704
 014=907.003
 014=907003
 BOOM ARM ASSY 200 OHM WHITE
 BOOM ARM ASSY 200 OHM WHITE
 BOOM ARM,UPPER DT108/DT109
 BOOM ASSY 2000HM BLACK DT108/9
 BOOM ASSY W/MIC DT290/DT280
 BOOM DT280/DT290
 CABLE DT250 442070
 CABLE MIC-MUFF DT108.4/109.4
 CABLE,4-PIN FEMALE DT190
 CABLE,MIC-MUFF DT108/DT109
 CABLE,OVERHEAD DT108/DT109
 CONE NUT,MIC HINGE DT108/DT109
 COVER PLATE,LEFT DT108 108.448
 COVER PLATE,LEFT DT108 WHITE
 COVER PLATE,RIGHT WHITE DT109
 COVER,50 OHMS WHITE DT109
 EAR PAD,VELOUR DT200 SERS (PR)
 EAR PAD,VELOUR DT250/280(PAIR)
 EARPAD DT108/DT109 (PAIR)
 EARPAD DT108/DT109 (PAIR)

014=931.532
 014=926.356
 014=333.395
 014=908.699
 014=908.677
 014=933.395
 014=107.840
 014=908.715
 014=317.438
 014=108.294
 014=346.748
 014=101.907
 014=107.972
 014=921.761
 014=902.954
 014=334.286
 014=109.061
 014=128.031
 014=144.983
 014=108.189
 014=109.207
 014=930.761
 014=904.165
 014=330.700
 014=900.257
 014=900.249
 014=174.068
 014=159.271
 014=103.101
 014=313.599
 014=280.836
 014=904.157
 014=504.157

BOGEN IMAGING

378=R516,07
 378=D001 JS3
 378=R250,488
 378=R516,05
 378=R250,12
 378=R079,54
 378=R501,24
 378=161.50
 378=R550,254
 378=R516,22
 378=R190,311
 378=R700,32
 378=R250,11
 378=R055,68
 378=R190,392
 378=R055,389
 378=R055,388
 378=R555,03
 378=R250,42B
 378=R055,390
 378=R501,30
 378=R515,08
 378=R515,13
 378=R114,05
 378=R519,22
 378=R501,19
 378=R190,42
 378=R540,07
 378=R250,41
 378=R127,08
 378=R030,05
 378=R3,0020
 378=R501,03
 378=127.08
 378=R058,24
 378=R501,18
 378=R351,08
 378=R190,18

BOSE [VIEW ONLINE](#)

505=257241
 505=291024-001
 505=290853-001
 505=296712

EARPAD DT150/180/190 (PAIR)
 FAT SIDE SUPP W/PAD ETC..DT108
 FOAM INSERT EARPHONE DT108/109
 FOAM INSERT EARPHONE DT108/109
 FOAM INSERT MIC DT108/DT109
 FOAM INSERT,EAR DT990/DT990PRO
 HEADBAND ENDSTOP DT100 SERIES
 HEADBAND PAD DT108/DT109
 KNURLED DISC BLACK
 KNURLED DISC WHITE
 LOWER BOOM ARM BLACK DT108/109
 MAIN CABLE DT108/DT109 101.907
 MIC CAGE DT108/DT109 GREY
 MIC ELEMENT DT108/9 2000HM BLK
 MIC ELEMENT DT108/9 2000HM WHT
 RIVET,BLACK DT102/DT108/DT109
 SCREW A DT108 109.061
 SCREW B(M2+5.5)
 SCREW C M1.7X10 DT108/DT109
 SCREW CAP DT108/DT109
 SCREW,BOOM ARM DT108/109
 SCREW,MAIN CABLE 9810 DT SERIS
 SLIDE,HEADBAND DT290/DT250
 SLIM SUPPORT PAD
 SWIVEL ARM FIX ASSY DT108 BLAK
 SWIVEL ARM KIT GREY DT108/109
 TAPER NUT
 THREADED INSERT,MIC DT108/109
 TRANSDUCER 200 OHM
 UPPER BOOM ARM SECTION BLACK
 WINDSCREEN,FOAM DT109/DT190
 YOKE,EARPIECE DT280/DT290
 YOKE,STRAP DT290/DT250

BASE,MOUNTING PLATE 516 HEAD
 BUSHING KIT (SET OF 3) GITZO
 FIXED MIDDLE COLLAR 350MMVB2
 FLANGE ASSY,RIGHT 516
 FOOT (RUBBER ONLY) 350B
 FOOT,RUBBER 755B
 FRICTION DISK 501
 GEAR,CRANK HANDLE 3046
 HANDLE CLAMP,REMOTE(UNIVERSAL)
 HANDLE,LOCKING LEVER 516
 KNOB 3001N
 KNOB,PLATE RELEASE 700RC-2
 LEG ASSY,LOWER 350B
 LEG LOCK KNOB ASSY 3001N/055XD
 LEG LOCK,LOWER (NEWER) 3221WN
 LEG LOCK,LOWER 755B
 LEG LOCK,UPPER 3020/3021/755B
 LEG STRUT ASSY 755B/554
 LEG,BLACK 350SPRB
 LEVEL ASSEMBLY,UPPER 755B
 LEVER BOLT,HANDLE 501
 LEVER,LEG RELEASE 525MVB
 LEVER,LOWER LEG
 LOCK KNOB 3128/3126/3130
 LOCKING CASTING,HANDLE 519
 LOCKING KNOB,QIK REL 3433/516
 LOWER LEG LOCK 3001/3025
 LOWER SLIDING BLOCK
 RETAINING HOOK 350SPRB
 RUBBER STRAP 3127/3137
 SCREW W/THUMBWHEEL 1/4-20 3126
 SCREW,COLUMN (5 PACK)3046/3068
 SIDE PLATE,RIGHT 3433/501
 STRAP,LEGS 3127 DOLLY
 STRUT KNOB 350SPRB
 TILT KNOB,LOCKING 3433/501
 UPPER LEG ASSY,MV82K
 UPPER LEG LOCK 3001

CROSSOVER ASSY 402II
 DRIVER 4.5" 102
 ENVIRONMENTAL KIT MODEL 32
 GRILL KIT,WHITE DS16F

505=259158-001
505=119278-001
505=121777-501

MOUNTING BRACKET MODEL 32
SPEAKER 4.5" 402/402W
SPEAKER 4.5" 802/802II

>> BRETTFORD

481=012-0638
481=012-0148

INSERT, SWIVEL CASTER BBULC48
TUBE CAP, SQUARE PLASTIC BLACK

>> BROOKE-SIREN [VIEW ONLINE](#)

522=KA0446

KNOB, GAIN CONTROL FCS960

>> CANON [VIEW ONLINE](#)

438=DY1-8611-000
438=DY1-8135-000
438=VD7-0601-201
438=DF1-1514-020
438=WS1-5778-000
438=DG1-3740-000
438=YF1-0008-000
438=DG1-3425-000
438=XA1-7170-309
438=DG1-3706-000
438=DG1-7395-010

DRIVE GEAR ASSY DMGL2
DRUM BASE ASSY DMGL1
FUSE FU3201 DM-GL1A/XL1
IDLER GEAR ASSY DMGL2
JACK, MIC GL1
LENS CAP GL1/GL2
LENS CAP, FRONT XL1/XLH1/XL2 A1
REEL TABLE, SUPPLY DMXL1
SCREW, BOTTOM COVER GL2A
ZOOM KEY ASSY DMGL1
ZOOM KEY CONTROL ASSY DMGL2A

>> CLEAR-COM [VIEW ONLINE](#)

017=AN-685/A
017=AN-685/C
017=250302
017=251244
017=251082
017=250301
017=510116
017=280399
017=510106
017=280134
017=500113
017=506024
017=507000
017=500115
017=505000
017=506007
017=140011
017=250009
017=280389
017=480097
017=251063
017=250291
017=390036
017=390047
017=390005
017=390054
017=390018
017=390021
017=506008
017=500114
017=250303
017=515000
017=506010
017=470048
017=400007
017=280012
017=280388
017=510140
017=510107
017=506011
017=506023
017=505017
017=506019
017=250299
017=250300
017=280387
017=505030

ANTENNA, RCV BLACK WTR670/680
ANTENNA, TRSMT GREEN WTR670/680
BELT CLIP RS500 SERIES
BELT CLIP RS600 SERIES
BELT CLIP WTR670
BOTTOM BEZEL 500 SERIES
BUTTON ASSY, TALK RM440
COVER, MENU WTR670
DPDT SWITCH RM/MS440
DRAWBOLT 501
EAR ELEMENT CC26
EAR ELEMENT CC95/CC260
EAR PAD CC40
EARPAD CC26
EARPAD CC85
EARPAD CC95/CC260 (EACH)
EARSOCK ES-1 (PAIR)
HANGER, HANDSET HS6
HOOK, BATTERY WTR670
IC, LOGIC ARRAY, RS501, 502
KNOB, VOLUME CONTROL RS601
LABEL FOR BEZEL RS501
LAMP MS812, 811A
LAMP OL6235BP MS232
LAMP, TALK BUTTON MS/RM400
LAMP, TALK BUTTON RM/MS440
LED, CALL RED RS501
LED, TALK GREEN RS501
MIC ELEMENT CC95/CC260
MIC FOAM WINDSCREEN FOR CC26
MOUNT BRACKET RS500/501/502
PAD, RUBBER TALK/CALL BTN RS501
POP FILTER, MIC CC95
POT, VOLUME RS501 (SERIES)
POWER ADAPTER PK5/AB100
SCREW, BELT CLIP RS601
SCREW, BELT CLIP WTR670
SWITCH W/BUTTON TALK WTR670/680
SWITCH, CALL AND TALK KB211
TAPE, POP FILTER CC95
TAPE, TEMPLE PAD CC95
TEMPLE CUSHION CC85
TEMPLE PAD CC95
TOP BEZEL RS501 W/O LABEL
TOP BEZEL, NO LABEL RS502
WASHER, BELT CLIP WTR670
WINDSCREEN CC250/CC85

>> COMMUNITY L&S [VIEW ONLINE](#)

342=103424R
342=104476R
342=PZT2R
342=SK3HP-SINGLE

DIAPHRAGM HF XLT47/XLT42E/43E
DRIVER, HF UC-1 XLT500/R. 5-94Z
DRIVER, VERY HIGH FREQ. CSX57S2
FUSE LAMP CROSSOVER, EACH

342=SK3HP
342=107423R
342=106363R
342=104711R
342=104636R
342=PZT1R
342=107589R
342=106064R
342=106045R
342=104985R
342=106043R

FUSE LAMPS XOVERS (6 PACK)
GRILLE ASSY R5 STAINLESS STEEL
GRILLE ASSY R5HP STNLESS STEEL
GRILLE WET312-94HWS STNLSSTEEL
HF DRIVER CPL23/27
HF DRIVER FOR CSX35/25/28-S2
HF HORN ASSY MVP12M/MVP15M
HORN ASSY W/XOVER MVP37/36
TWEETER ASSY MVP38/MVP25/MVP35
WOOFER 12" R.5/R2 SERIES
WOOFER 15" MVP37/38/15HO/36

>> CREST AUDIO

201=98500156
201=73717241
201=73717242
201=C68000046
201=30901922
201=C58500006
201=C58500008
201=C58-20
201=71191017
201=77500003
201=76500001
201=71322446
201=94000006
201=30400194
201=30400193

CONNECTOR W/WIRES, FADER GTX
CONNECTOR, PHOENIX 2P CM2208
CONNECTOR, PHOENIX 3P CM2208
FADER, STEREO/MONO CENTURY GTX
GUARD KIT, FAN 2U FOAM FILTER
KNOB, FADER GRAY CENTURY GTX
KNOB, FADER RED CENTURY GTX
KNOB, VOLUME FA1201/PRO9200
POTENTIOMETER, GAIN XR20
RESISTOR .33 OHM 5W FA1201
RESISTOR 2.2 OHM 1W FA1201
SWITCH, GROUP ASSIGN X8 XR20
TRANSISTOR 2SA1302
TRANSISTOR (MUL21194)4029
TRANSISTOR, (MUL21193) 2SA1553

>> CROWN [VIEW ONLINE](#)

024=D6944-9
024=D7696-4
024=131445-3
024=D6791-4
024=D6640-3
024=A10173-1
024=C9677-3
024=140305-1
024=D8125-3
024=D8399-4
024=A10285-13
024=C10034-4
024=137557-4
024=M45887-3
024=C9785-4
024=C10000-5
024=102595-3
024=135360-1
024=D8141-0
024=D8128-7
024=132240-10604
024=C6419-3
024=C8573-5
024=C4751-1
024=102659-1
024=C8188-2
024=D8421-6
024=D6916-7
024=D7403-5
024=M46170-3
024=A11565-M090M
024=A11384-C140M
024=A11565-M030P

AIR FILTER (1) MA600/1200/2400
AIR FILTER (2) MA600/1200/2400
BRKT, CE2000A +ADD 132240-10604
CABLE PCC160 WHITE
CABLE PCC160/PCC170/PZM BLACK
CLIP (VELCRO) FILTER MA/MT/PB/CT
CONNECTOR, PHNX 3P CBL CTS1200
FAN 80X80X25 XLS402
FOAM LINER, MIC BOTTOM CM311A
FOAM PAD, CHEEK CM311/CM312
FUSE, POWER 2A D75A
LOCKING COLLAR MB3
PCB, MAIN CE2000A +ADD C6419-3
POP FILTER, WINDSCREEN CM311
POT, 5K LNR W/21 DET COMTEH400
POT, VOLUME 20K D45/D75A
POT, VOLUME W/CLICK CE2000
POT, VOLUME XLS402, ORIGINAL
RING CLIP, MIC BOTTOM CM311A
SCREEN, MIC BOTTOM CM311A
SCREW(3)CE2K +ADD A11565-M030P
SHUNT, CE2000A +ADD 131445-3
TRANSISTOR 2SA1186 MT1200/CT
TRANSISTOR, OUTPUT (GRADE ?)
TRANSISTOR, OUTPUT CE/810 GRD#1
TRANSISTOR, OUTPUT GRADE #1
WINDSCREEN CM312/312A
WINDSCREEN LM201B
WINDSCREEN WS5
WINDSCREEN, FOAM LM300/300A
WIRE, CE2000 +ADD A11384-C140M
WIRE, CE2000A (END OF KIT)
WIRE, CE2000A +ADD A11565-M090M

>> DA-LITE SCREEN [VIEW ONLINE](#)

515=86474
515=88068
515=46928
515=44828
515=52751
515=85875
515=89196
515=40902
515=57923
515=84413

CAP, WHITE OUTER SLAT
FRAME, WALL HANGER BRACKET
LEG SHOE, BLACK BGS SYSTEM
RIVET, HINGE LEFT LEG FAST FOLD
SCREW, HANGER BARACKET
SNAP CAP .875
SPEEDY CRANK DELUXE FASTFOLD
SPEEDY CRANK STANDARD FASTFOLD
SPRING BUTTON ASSY PICTURE KING
WIRE BY FOOT, 1/8 7/7

