

084=55A8087 SWITCH,POWER/MUTE UT2/ULX2  
 084=51A312 TRANSFORMER 527A  
 084=65A1071A UPPER BALL,BOOM PIVOT SM2/512  
 084=95B2064 WINDSCREEN MX202W WHITE  
 084=49A55 WINDSCREEN VP64,AMS24 BROWN  
 084=49A91 WINDSCREEN VP88  
 084=49B105 WINDSCREEN WL93 TAN  
 084=49A130 WINDSCREEN,BLACK SM63LB  
 084=49A66A WINDSCREEN,FOAM SM98/WM98  
 084=90D3013 WINDSCREEN,INTERNAL 1/2 BETA87  
 084=90WP1371 WINDSCREEN,MIC WH30

### >> SKB

869=FO-1669 CUBE FOAM 3I-2011-7B-C(SKB-WEB)  
 869=FO-510 DICED FOAM,23X29X1" (SKB-WEB)  
 869=SKBAC1 NUT RETAINER CLIP W/SCREW (12)

### >> SONY [VIEW ONLINE](#)

161=1-506-589-11 ADAPTER MINI/F-1/4M MDR7506AKG  
 161=2-545-240-01 ANTENNA BRACKET WRT805A  
 161=1-501-458-12 ANTENNA WRT820/WRT822A  
 161=1-754-073-12 ANTENNA, LONG WRT805A/WRR805A  
 161=1-501-945-11 ANTENNA, SHORT WRT800/805A  
 161=A-4521-033-H BATTERY CASE WRT820A/WRT822A  
 161=1-756-425-21 BATTERY, RECHARGEABLE LIP4WM  
 161=4-927-649-01 BELT CDP2700/CDPD500  
 161=2-545-245-01 BELT CLIP WRT805B/WRT805A  
 161=3-653-387-00 BELT LM V09800/V05850  
 161=3-164-243-01 BELT,CAPSTAN CCP1310F  
 161=3-562-462-00 BELT,CAPSTAN PCMR500  
 161=3-359-417-01 BELT,FLAT CAPSTAN TCWR690  
 161=4-913-325-01 BELT,TAKE UP PCMR500  
 161=A-7031-100A BLOCK ASSY,PRISM DSR250  
 161=A-8274-968-B BRACKET,HOT SHOE DXF51  
 161=3-164-272-02 BRUSHES,ELECTROSTATIC CCP1310F  
 161=3-368-398-01 BUSHING PCM2300  
 161=2-346-620-1 BUTTON,EJECT MDSE11  
 161=1-580-792-12 CABLE W/PLUG MDR7506  
 161=1-824-0974-1 CABLE,A/V DSRPDX10  
 161=A-4510-056-A CAPSULE FOR ECM44B  
 161=3-007-485-01 CASSETTE LID PCMR500/700  
 161=1-794-276-11 CONNECTOR 4P SQUARE DCRTRV38  
 161=1-770-496-11 CONNECTOR 4P SQUARE DV DSR30  
 161=KMC9BPD-4PR CONNECTOR,HIROSE WRT SERIES  
 161=3-060-543-01 COVER,EJECT DSRPD170  
 161=DT10CLA DAT CLEANING TAPE  
 161=4-954-041-22 EAR PAD (L) MDRV509  
 161=4-954-041-13 EAR PAD (L) MDRV600  
 161=4-954-042-22 EAR PAD (R) MDRV509  
 161=4-954-042-13 EAR PAD (R) MDRV600  
 161=X-2113-123-1 EARPAD MDR7502/MDRV4  
 161=2-115-668-03 EARPAD MDR7506/MDRV6 (EACH)  
 161=1-787-342-31 FAN 35MM SQ 320MM CBL LMD1410  
 161=2-539-598-01 FOAM WINDSCREEN FOR ECM166  
 161=2-113-132-11 HANGER,LEFT MDR7506/MDRV504  
 161=8-759-566-52 IC IC3303 VC-275 CBA GVD1000  
 161=6-708-889-01 IC,HVR1500  
 161=1-778-519-11 JACK,DV IN/OUT DCRPC1  
 161=1-691-737-41 JACK,MIC DCRTRV900  
 161=3-060-551-01 KNOB,EJECT DSRPD170  
 161=A-4540-185-A LAPEL CLIP ECM122BMP  
 161=X-2522-010-1 LAPEL CLIP ECM55B/66B HZ BLACK  
 161=8-753-209-13 LCD PANEL DSRPD170  
 161=X-3950-568-1 LENS CAP DSRPD150/DSRPD170  
 161=3-060-552-01 LOCK,EJECT DSRPD170  
 161=X-3168-437-1 MIC CLIP ECM88  
 161=X-2536-801-1 MIC CLIP FOR ECM166BMP  
 161=X-2190-774-1 MIC CLIP UTXB2V  
 161=3-709-071-02 MIC CLIP UWPX1  
 161=2-100-952-00 MIC STAND SCREW ADAPTER,AN820A  
 161=1-576-286-21 MICRO FUSE 1.4A DCRVX2000  
 161=1-656-400-13 PCB FP217 DCRVX1000  
 161=X-3951-680-1 PINCH ARM ASSY DCRTRV20  
 161=X-3162-306-1 PINCH ROLLER CCP2300/CCP1310F  
 161=X-3337-610-1 PINCH ROLLER PCM2500A/DA30  
 161=1-230-481-11 POT 20K PHASE/CHROMA PVM5310  
 161=1-479-283-19 POWER ADAPTER ACL15 DCRTRV240  
 161=3-678-339-01 PUSH BUTTON WRT805A/WRT806A  
 161=1-477-723-11 REMOTE CONTROL RMT-D152A

161=1-211-987-11 RESISTOR 560HM SMD DSR30  
 161=3-608-303-01 RING,RUBBER MIC DSRPD170  
 161=2-113-149-01 RING,URETHANE, FOR MDR7506  
 161=3-053-121-61 SCREW M2 SPRING BOLT DSRPD170  
 161=3-973-497-41 SCREW,M1.7 DCRPC9  
 161=7-627-552-08 SCREW,PRECISION 1.7X2.5 WRT820  
 161=7-627-553-38 SCREW,PRECISION 2X3 WRT860A  
 161=3-964-010-01 SCREW,TRIPOD PLATE DCRVX1000  
 161=3-060-549-01 SHEET,EJECT DSRPD170  
 161=X-3948-444-1 S-REEL TABLE DCRVX2000  
 161=1-473-139-21 SWITCH BLOCK,VCR CTRL DCRVX1K  
 161=3-315-414-31 WASHER,SLIT GVD300  
 161=X-316-790-21 WINDSCREEN ECM350BC/310/122BMP  
 161=X-252-202-31 WINDSCREEN ECM55B  
 161=3-709-070-01 WINDSCREEN UWPX1  
 161=3-048-481-01 WINDSCREEN,MIC ECMNV1/HRVR1U

### >> SOUNDCRAFT [VIEW ONLINE](#)

089=DD0369 FADER,C/R MODULE SAC200  
 089=DD0412 FADER,MONO K1  
 089=DD0375 FADER,MONO SAC200  
 089=DD0370 FADER,PGM/STUDIO MODULE SAC200  
 089=DD0374 FADER,STEREO SAC200  
 089=FH0787 JACK,INSERT (STEEL) K2  
 089=KA0344-02 KNOB,FADER DK BLUE SERIES 4&5  
 089=KA0345-02 KNOB,FADER RED SERIES 4 & 5  
 089=KA0346-02 KNOB,FADER WHITE SERIES 4 & 5  
 089=KA0347-02 KNOB,FADER YELLOW SERIES 4 & 5  
 089=KA0107 KNOB,GAIN RED SERIES 4  
 089=KA0235 KNOB,GAIN RED SM12  
 089=DM1216 POT,100K+10K DUAL EQ SM12  
 089=DD0466 POT,CHANNEL FADER MONO SERIES4  
 089=DM1165 POT,INPUT GAIN MONO SERIES 4  
 089=DM1140 POT,INPUT GAIN MONO SM12  
 089=DM1361 POT,INPUT GAIN STEREO SERIES 4  
 089=DM1292 POT,MIX B VOL/CONTOL RM GHOST  
 089=DM1130 POT,ROTARY AUX CTRL SM12  
 089=DM1287 POT,TAPE RETURN GHOST  
 089=NA0328 SCREW,FADER SERIES 4  
 089=DF0660 SWITCH,MUTE/PFL FOLIO FX8/LX7  
 089=DF0530 SWITCH,PHANTOM/SOLO K1/K3

### >> SPIRIT BY SOUNDCRAFT [VIEW ONLINE](#)

266=DD0438 FADER,MONO CHNL LIVE4/SPIRIT8  
 266=BS7009R-S08 IC NJM5532 SMT LIVE 4-2  
 266=FH0786 INSERT JACKS SERIES 2  
 266=KA0228 KNOB,FADER WHITE FX16/FX8/LIVE  
 266=KA0303 KNOB,ROTARY YELLOW FX8/FX16  
 266=DM1328 POT,ROTARY GAIN MONO LX7  
 266=HB0172 POWER SUPPLY 10-2/FOLIO 12-2  
 266=HB8052 POWER SUPPLY FOLIO NOTE PAD  
 266=NA0346 SCREW,END CAP MOUNT LIVE 8-32

### >> STANTON

092=NHP0011 BELT,DRIVE STR8 SERIES  
 092=PS1808 POWER ADAPTER RM3/SK2F  
 092=SHP0003 POWER CABLE

### >> TANNY [VIEW ONLINE](#)

587=8001 0210 SPEAKER,SYSTEM 800/A/CMS8-60  
 587=5DR53100 TWEETER PROTO-J  
 587=7900 0457 TWEETER REVEAL  
 587=7900 0891 TWEETER REVEAL 6D/8D

### >> TECHNOMAD

829=785 SPEAKER 12" WOOFER CAIRO/NOHO  
 829=285 TWEETER ASSY VIENNA 16  
 829=284 WOOFER 6.5" VIENNA 16

### >> TCH CASE HARDWARE

506=512-6014900 BOLT,GRILLE/SPKR 10-32/1-1/4"  
 506=508-3901900 CARPET COVERING 48" BLK PER YD  
 506=502-1323900 CORNER,2 LEG METAL BLACK  
 506=502-1400900 CORNER,2 LEG PLASTIC STACK BLK  
 506=502-1321801 CORNER,2 LEG WRAPAROUND NICKEL  
 506=502-1300900 CORNER,3 LEG METAL BLACK  
 506=502-1300801 CORNER,3 LEG METAL NICKEL

506=502-1002800  
 506=503-1606900  
 506=503-1603900  
 506=500-310801  
 506=500-110900  
 506=500-100800  
 506=500-125800  
 506=500-232990  
 506=500-148800  
 506=501-2487800  
 506=501-2481800  
 506=513-7011900  
 506=512-6002800  
 506=501-2500800  
 506=501-5733800  
 506=501-573800

CORNER,BALL TYPE 2.5" HD ZINC  
 FOOT,RUBBER MEDIUM 1.5"  
 FOOT,RUBBER SMALL .88X.53  
 HANDLE STRAP  
 HANDLE,HVY DUTY MED REC BLACK  
 HANDLE,HVY DUTY MED REC ZINC  
 HANDLE,RECESSED 5X7 HD ZINC  
 HANDLE,SPKR CAB REC METAL BLK  
 HANDLE,SURFACE MOUNT ZINC  
 KEEPER,LATCH SMALL (SURFACE)  
 LATCH,BUTTERFLY SMALL(SURFACE)  
 SPEAKER CLAMP HVY DUTY BLACK  
 T-NUT,SPEAKER MOUNT 10-32  
 TWIST CATCH RECESSED 5X6.5 ZNC  
 TWIST CATCH,MED W/DOWEL 4X4  
 TWIST CATCH,RECESSED 4X4 ZINC

### TEAC / TASCAM [VIEW ONLINE](#)

095=5800106900  
 095=5800063100  
 095=5534468000  
 095=5534692001  
 095=V00013500B  
 095=553484400  
 095=13-101300010020  
 095=V00141900A/1.TC  
 095=5740003400  
 095=V00018400A  
 095=5800120802  
 095=5800120902  
 095=5772925400  
 095=3M002870  
 095=3E0092511A  
 095=M00774500A  
 095=M00607200B  
 095=5800115800  
 095=M02508800A

BELT,CAPSTAN 112B/122MKII  
 BELT,CAPSTAN 122/122B/133  
 BELT,CAPSTAN 22-4/A3440/A3340S  
 BELT,CAPSTAN X1000R/2000R/4010  
 BELT,LOAD/TRAY CDA500 DA30MKII  
 BRAKE SHOE 122  
 BULB,BACKLIGHT CDP1250  
 CD MECH V3 (V1 MOD@TEAC) CC222  
 HUB ADAPTER 1/2" TSR8+  
 IDLER GEAR FOR DAP1  
 IDLER WHEEL "A" 112/B/122MKII  
 IDLER WHEEL "B" 112/B/122MKII  
 LEAD LAMP,VU METER  
 MOTOR,CAPSTAN 424/202/302MKII  
 POWER SUPPLY 424/MKII/MKIII  
 PULLEY ASSY,122MKII/112MKII  
 REEL TABLE,TAKE-UP DA88  
 SPRING  
 TRAVERSE MECHANISM CD01UPRO

### TELEX [VIEW ONLINE](#)

097=700331001  
 097=877980  
 097=52487-001  
 097=92873-001  
 097=86631-056  
 097=86631-059  
 097=86631-054  
 097=86631-055  
 097=63465-006  
 097=64319-001  
 097=71115-000  
 097=25339-001  
 097=64311-053  
 097=25027686006  
 097=300100212  
 097=300100220  
 097=550002-000  
 097=02189  
 097=CRW-5232AX  
 097=700453-001  
 097=40055-10  
 097=64407-001  
 097=59840006  
 097=46108-3  
 097=810109  
 097=60904-048  
 097=1608P3S  
 097=700141000  
 097=35772-000  
 097=64301-000  
 097=560353001  
 097=590097000  
 097=800024-001  
 097=63444-001  
 097=590402-002  
 097=590626-001  
 097=700719-003  
 097=700719-002  
 097=70664-000  
 097=70608-000

ADAPTER,HEADBAND HR1  
 ANTENNA TR500  
 BEARING,CAPSTAN  
 BELT CLIP IC1/TR800  
 BELT REPLICA  
 BELT X-GEN  
 BELT,DRIVE COPYETTE 121  
 BELT,DRIVE COPYETTE 123  
 BEND RELIEF,MAIN CABLE HR1  
 BOOM HOUSING ASSY PH8  
 BOOM HR1  
 CABLE,BOOM (PER FOOT) HR1  
 CABLE,MAIN PH88  
 CABLE,POWER ICW3-POWER SUPPLY  
 CABLE,Y-CORD DISCOVERY  
 CABLE,Y-CORD ODESSY  
 CABLE,MAIN (PER FOOT) HR1  
 CAPSULE,MIC MP753/MP756/WP300S  
 CD DRIVE,CRW-5232AX  
 CLAMP KNOB HR1  
 CONNECTOR,3PIN XLR BP1000  
 CORD ASSY,3 PRONG PH8  
 COVER,EARBUD(12 PK) PH150/SEB1  
 CUP,REAR WP300S  
 CUSHION,BATTERY DOOR SR50  
 DAMPING CLOTH,MIC HR1  
 DRIVE, SPINWISE  
 DRIVER COVER HR1  
 EAR CUSHION COVER PH1  
 EAR FOAM,EACH,FOR PH8  
 EAR PAD HR2/HR2R5 (EACH) FIN  
 EAR PAD OH1V  
 EARPAD HR1  
 EARPAD PH1 (EACH)  
 EARPAD PH4/PH5/PH8 (EACH)  
 EARPAD PH88/PH44 (EACH) FIN  
 FLYWHEEL,CAPSTAN 121 YELLOW DT  
 FLYWHEEL,CAPSTAN COPYETTE 121  
 FOAM PAD,MIC WP300S  
 FOAM PH2

097=63124-018  
 097=64310-000  
 097=64305-000  
 097=470693  
 097=04125-1  
 097=63709-001  
 097=700856-001  
 097=64308-107  
 097=300028-003  
 097=85677  
 097=61585-037  
 097=700039-002  
 097=700228-000  
 097=700038-002  
 097=700058-000  
 097=800499-100  
 097=800198001  
 097=590002000  
 097=800818-002  
 097=ACC000036NA  
 097=800827001  
 097=64308-007  
 097=64307-003  
 097=55792-006  
 097=700454-000  
 097=700057-000  
 097=56016-004  
 097=590404-360  
 097=51856-002  
 097=51845-018  
 097=46106  
 097=700450-101  
 097=90527-006  
 097=54349001  
 097=90672000  
 097=532047000  
 097=64442-000  
 097=70533-000  
 097=70531-001  
 097=70531-003  
 097=90707374-002  
 097=95524-000  
 097=50013037  
 097=59774-003  
 097=59835-000

FOAM,MIC HR1  
 GLIDER ARM ASSY PH8  
 GLIDER SPRING PH8  
 GRAY SHAFT 723439-5 BTR800  
 GRILLE,BLACK METAL WP300S  
 HEADBAND SPACER PH-1  
 HOLDER,TEMPLE PAD HR1  
 HOUSING ASSY PH88  
 MIC ELEMENT HR1  
 MIC ELEMENT ND767A/MT2500  
 MIC ELEMENT PH1/2/3  
 MIC HOUSING,BOTTOM HR1  
 MIC HOUSING,BOTTOM PH10  
 MIC HOUSING,TOP HR1  
 MIC RING HR1  
 MIC/BOOM ARM HOUSING ASSY PH88  
 PAD,HEAD HR1  
 PAD,TEMPLE HR1  
 PINCH ROLLER COPYETTE 123  
 POWER SUPPLY R10/RE2  
 PRESSURE ROLLER XGEN  
 RECEIVER ASSY,SPEAKER PH8  
 RECEIVER HOUSING PH8  
 RECORD HEAD ACC2000  
 RETAINER PIN HR1  
 SCREEN,MIC HR1  
 SCREW  
 SCREW  
 SCREW NO2-28X3/8  
 SCREW,MIC HOUSING HR1  
 SHOCKMOUNT,MIC WP300S  
 SLIDER HR1  
 SPINDLE COPYETTE 1-2-3  
 SPRING,CARRIER 1-3 EH  
 SPRING,RETAINER 1-3 EH  
 SWITCHING POWER SUPPLY ICW3  
 TEMPLE PAD PH1 (EACH)  
 TEMPLE PAD,DUMMY SIDE PH88  
 TEMPLE PLATE PH8  
 TEMPLE PLATE PH88  
 TOP PLATE BP1000  
 WASHER,DUST GUARD  
 WASHER,FIBER  
 WINDSCREEN FOR PH8/PH44 PH5  
 WINDSCREEN,MIC PH8/PH88

### TELEX - WIRELESS MICS [VIEW ONLINE](#)

215=879220-2  
 215=879220-3  
 215=879220-4  
 215=877960-1  
 215=879248-2  
 215=870601-3  
 215=877960  
 215=870601-5  
 215=879010  
 215=870533-3  
 215=870533-4  
 215=450388  
 215=57970-000  
 215=250233  
 215=250234  
 215=450593  
 215=PAR000097000  
 215=71315000  
 215=878557  
 215=71215000  
 215=878948  
 215=92873001  
 215=52887000  
 215=657591  
 215=9160563603  
 215=690419  
 215=470261  
 215=690460-1  
 215=53980-000  
 215=57970000  
 215=450359  
 215=35623010

ANTENNA 485-553.9 TR XMT BLACK  
 ANTENNA 554-635.9 TR XMT YELLO  
 ANTENNA 636-725.9 TR XMT GREEN  
 ANTENNA AAT2/ST200/ST300  
 ANTENNA BTR200/BTR300 YELLOW  
 ANTENNA HT450 WHITE  
 ANTENNA OLDER SOUNDMATE AAT1  
 ANTENNA RED HT450 662.7MHZ  
 ANTENNA USR100/WT1000/UR700RE2  
 ANTENNA WT450 XMITTER WHITE  
 ANTENNA WT450 XMITTER YELLOW  
 BATT HOOK/PLATE TR700/TR800  
 BATTERY CLIP  
 BATTERY CONTACT (-) LT100  
 BATTERY CONTACT (+) LT100  
 BATTERY DOOR SR50 TRANSMITTER  
 BATTERY LATCH TR700/TR800  
 BATTERY PAK ALKALINE TR800/700  
 BATTERY SLED 6-AA TR200/TR300  
 BATTERY SLED FOR TR500/TR600  
 BELT CLIP ASSY TR200/TR300  
 BELT CLIP TR700/TR825/TR500  
 BELT CLIP WT50/55 SEE 51847011  
 BULKHEAD ADAPTER,ANTENNA CABLE  
 BUTTON,PUSH TO TALK  
 CABLE,RG58 A/U W/TNC(10)CXU10  
 CASE,BACK TR300/TR200/TR500  
 COAX ASSY TRANSMIT BTR700/800  
 CONNECTOR,4P LEMO WT450/WT100  
 CONTACT,BATTERY TR200/TR300  
 COVER,BATTERY SLED ALKLN TR800  
 ELBOW W/O TUBE ET4

