

WARNING:

LIGHTING:

Never point your Dukane Camera 101 at direct sunlight. Subjecting the Camera 101 "eye" to direct sunlight will discolor the filter over the CCD chip and create an adverse picture.

POWER SUPPLY:

Do Not use other power supplies (even if they fit). They will produce improper voltage or reversed polarities. This will seriously damage your Camera 101® and void your Warranty. Should you need a replacement power supply, contact Dukane.

WARRANTY

To activate the one year limited warranty on your new Dukane Camera 101 simply complete the warranty card enclosed and return to us. The warranty will not apply if your serial number has been removed or if the product has been tampered with, disassembled or damaged by misuse, accident, modification or unauthorized repair.

INFORMATION TO THE USER:

Changes or modifications not expressly approved by the party responsible for compliance could void the users authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna and/or: Increase the separation distance between the equipment and the receiver: and/or Connect equipment into the receiver: and/or Connect equipment into an outlet on a circuit different from that which the receiver is connected: and/or Consult your dealer or an experienced radio/TV technician for help.

DUKANE

2900 Dukane Drive
St. Charles, IL 60174

Phone: (630) 584-2300
Fax: (630) 584-5156

INS-VFDUK

DUKANE

Camera 101



Instruction Manual

Using your Dukane Camera 101

1. Remove the Camera 101 from the shipping carton.
2. Connect the Video and Power cables.

CONNECTING THE VIDEO CABLE:

Connect the cable into the "Video In" connector of the TV/Monitor, VCR, Video Projector or computer.

NOTE:


Consult your owner's manual when using any of these components for operating procedures to accept a video signal.

CONNECTING THE POWER SUPPLY:

Simply plug the power supply into a 110 electrical outlet. The "On/Off" button is located on the back of your Camera 101, power is indicated by an illuminated light.

- Do Not use other power supplies (even if they fit). They will produce improper voltage or reversed polarities. This will seriously damage your Camera 101® and void your Warranty. Should you need a replacement power supply, contact Dukane.

Thank you for your purchase of a Dukane Camera 101!
IT'S READY TO GO!



POWER OUTPUT:


- TV/Monitor Connect video cable from the Camera 101 into the "Video In" connector of the TV/Monitor. If no "Video-in" is available, you may need an RF Modulator or a VCR recorder. **See owner's manual of TV/Monitor for operating procedures.**
- VCR (Recorder) Connect video cable from the Camera 101 into the "Video-In" connector on the VCR. Connect VCR cables from your VCR to TV. **See owner's manual of VCR for operating procedures.**
- Video Projector Connect video cable from the Camera 101 into the "Video-In" connector on the video projector. **See owner's manual of video projector for operating procedures.**
- Computers To connect the Camera 101 to a computer, the computer must have a "Video-In" connector. Should your computer not be so equipped, you must then purchase a video digitizing board. **See the owner's manual of the computer for the operating procedures.**

FOCUSING DIRECTIONS:

The focusing ring, located on the camera head, is similar to that of a 35mm camera. When using the standard 6mm lens, the light will automatically be adjusted for optimum viewing conditions, depending on the available light and options in use.

ACCESSORIES

Use only genuine Dukane Camera 101 parts and accessories - Power supply. They are made specifically for the Dukane Camera 101. Failure due to use of non-Camera 101 parts will void the manufacturer warranty!



Power Supply