



HAZE GEN MAX

USER MANUAL





Congratulations on the purchase of your new HAZE GEN MAX

Introduction

Thank you for selecting FX Works HAZE GEN MAX. Prior to use, please read and follow all instructions for the safety and best haze effects.

Danger of Electric Shock

- Keep this device dry. For indoor use only.
- Use grounded electrical outlet. Prior to use make sure the unit is operated at the rated voltage.
- Unplug hazer before filling its tank.
- Turn off or unplug when not in use.
- This machine is not water-proof. If moisture, water, or haze fluid gets inside the housing, immediately unplug the unit and contact a service technician or your dealer before using it again.
- If power cable is damaged, please acquire specific power cable or accessories replacements from manufacturer or an authorized dealer.

Danger of Burn

- For adult use only. Keep out of reach of children. Never leave the unit running unattended.
- No user serviceable parts inside.
- Place the haze machine in a well-ventilated area. Leave approximately one foot of space surrounding the machine.
- Never aim the machine at open flames or close to flammable items.
- Never add flammable liquids of any kind (oil, gas, perfume) to the haze liquid.
- Use Antari HZL haze liquid.
- If machine fails to work properly, stop using immediately. Drain haze liquid from the tank. Pack the unit and return it to your ANTARI dealer for service.

- Haze liquid is not drinkable. If it is accidentally swallowed, get medical service immediately. If haze liquid comes in contact with skin or eyes, rinse thoroughly with water.

Unpacking & Inspection

Open the box and verify that all equipment necessary to operate the system has arrived intact. Before beginning initial setup of haze, make sure that there is no damage caused during transportation. In the event that the machine cable is damaged, do not use it until contacting your dealer to get a new replacement.

What is included: 1 x Haze Machine
 1 x IEC Power Cord
 1 x User Manual (This booklet)

Operation

1. Place the unit on a flat surface. Plug in power to a grounded electrical outlet.
2. Fill haze liquid into the liquid tank. **DO NOT OVERFILL.**

Use only Antari HZL haze liquid. Any other types of liquid may cause health hazard and damage the unit. Use of any other liquid will void the warranty.

Always monitor and make sure that there is sufficient HZL liquid inside the tank during operation.

3. Turn on power switch. Machine will start to produce haze.

Timer Remote Control Operation

Each HAZE GEN MAX machine comes with a timer remote controller



Red button: Power ON and OFF

Green button: HAZE output

Yellow button: TIMER ON and OFF

Two rotary knobs: For setting TIMER's DURATION and INTERVAL

Technical Specifications

- Input voltage	AC 100-120V, 50/60Hz 7A
- Rated power	315W
- Fluid consumption	0.7 ml/min
- Fluid tank capacity	2.5 Liter (0.66 gallon)
- Compatible fluid	Antari HZL Haze Fluid
- Ambient temp. range	0 °C - 40 °C (32 °F-104 °F)
- Control	Manual Timer Remote
- Connection	IEC (Power)
- Dimension	L484 W250 H294 mm (L19.06 W9.84 H11.57 inch)
- Weight	12 kg (26.46 lbs)

FXWORKS



COBHZO100-FXW