
Easycon


EZ Series

XLR Cable Connector IDC - Version


Assembly Instructions




- First slide the housing onto the cable.
- Strip cable jacket and wires according to figure.
- Twist the shielding strands and bend the shield back over the jacket.



- Slide the prepared end of the cable into the contact holes.
 - 1 shield
 - 2 + 3 signal wires
- Position the shield between the finger (A)



- Position the cable in the insert so that the shield is between the ground contact and the jacket.




- Hold cable and insert in this position and put the cable retention element onto the insert .
- Press the cable retention down to the base part until it snaps in.

- Push the complete insert into the housing as shown (pay attention to the currect alignment between shell and assembly).

NOTE Female connector:

Press down the latching spring (PUSH) before entering the housing.



The assembly is finished when:

Female:

 The insert has snapped into the housing and the latch has returned to its original position.


Male:

- The insert has snapped into the housing.

Disassembly:

Female:

- Press the latching and the mating face completely down.
- Push the insert with the cable out of the housing.




NEUTRIK Zürich AG

Switzerland

Male:

 Press the mating face completely down and push the insert with the cable out of the housing.



NEUTRIK AG Liechtenstein

Tel.: +423/237 24 24 Tel.: +41 1/736 5010 Fax: +423/232 53 93 Fax: +41 1/736 5011 NEUTRIK (UK) Ltd. Great Britain

Tel.: +44 19 83/811 441 Fax: +44 19 83/811 439 NEUTRIK USA INC. USA

Tel.: +1 732/901 9488 Fax: +1 732/901 9608

2

NEUTRIK Tokyo Ltd. Japan Tel.: +81/3/5411 25551 Fax: +81/3/5411 2827 NEUTRIK Vertriebs GmbH Germany / Netherlands Tel.: +49 8131/28 08-0 Fax: +49 8131/28 08-30



